

QuickCube Dimensioning System

Model : WB900XLU1

Whether it is for your internal warehouse management system or for your freight and logistics requirements, the WB900XLU1 QuickCube will make obtaining accurate parcel dimensions and weight fast and simple. Supplied with standard software which is quick and easy to install allowing integration to 3rd party software without IT integration. Simply place the parcel on the WB900XLU1 QuickCube and then click a key to capture the information. Never make a manual entry error again!

FEATURES

WB900XLU1

- durable and fast (data captured in just a couple of seconds)
- user friendly PC interface
- metric or imperial units of measure
- weighs and measure at the same time
- volumetric weight calculation
- ultrasonic measuring sensors
- robust 4 load cell weighing design
- software compatible with Windows OS

SPECIFICATIONS

Dimensions (mm):	880 (W) x 880 (L) x 1130 (H)
Min Measuring Capacity (mm):	40 (W) x 40 (D) x 20 (H)
Max Measuring Capacity (mm):	820 (W) x 820 (D) x 940 (H)
Weighing Capacity & Graduation:	55 kg x 10 g
Power Supply:	240VAC
Measuring Sensor:	ultrasonic
Software operating:	Windows®
PC Interface:	USB
Operating Temperature:	10 - 30 °C

OPTIONS

- barcode scanner



Specifications may change without notice

▲ **Weighing Scales.**

Labels, Labelling Equipment, Packaging Equipment, Weighing Scales, POS Systems, Food Equipment, Maintenance & Repairs, Hire.