

eLabels with Hi-Touch

Model : TSEL42NTBBBH

DIGI eLabels are IP67 rated and designed to operate in temperatures between 0°C and 40°C. They're ideal for wet environments or where label washing is required to maintain high levels of hygiene and food safety. Perfect for butchery, deli and seafood labelling.

Built in hi-touch sensors at the top of each unit enable quick accurate PLU selection that communicates back to the scale, improving productivity, reducing customer waiting times and eliminating the need for operators to remember product PLU numbers.

FEATURES

TSEL42NTBBBH

- built in hi-touch sensor for wireless remote PLU selection
- water resistant IP67 rating
- long battery life
- flexible and customisable display
- attractive and high contrast display
- can operate at a low temperature (0°C)
- pricing errors are eliminated with reliable real time price and information updates
- full price integrity is maintained with dynamic pricing
- instant PLU selection with a quick tap on the e-label
- can be used with SM5000 series self-service scale to provide shoppers a fast and easy self-service option

OPTIONS

- eLabel stand (BL10110)
- eLabel mega clip (BL10111)



e-Label with Mega Clip

e-Label with Stand

Specifications may change without notice

SPECIFICATIONS

Dimensions (mm)	103 (W) x 89 (D) x 15 (H)
Screen Size	4.2"
Display Size (pixels)	400 x 300
(mm)	86 x 65
Display Resolution (dpi)	120
Display Colour	2 Colour: Black, White
Case Colour	Black
Operating Temperature	0°C to 40°C
Operating Humidity	85% Max. RH Non-Condensing
Frequency Band	2.419GHz ~ 2.480GHz
Data Rate	Up to 500 kbps
IP Rating	IP67
Compliance	RoHS
Power Source	3 x DC Cell Button Battery 3.0V (non-serviceable)
Net Weight	124 g



Step 1 - Tap

Tap eLabel for the product chosen. This triggers a signal for the product's PLU to be transmitted to the scale.



Step 2 - Weigh

Place the product onto the scale platter and select the relevant icon (PLU) for goods being weighed.



Step 3 - Print

Select "print label" on the weigh labeller screen. The label will be presented ready for you to place on the goods.

Specifications may change without notice