

Rotary Collection Table

Model: WPROTARY

Ideal for automated production lines, Rotary Collection Tables are commonly utilised to accumulate finished packs ready for the next production process.

Wedderburn's Rotary Collection Table is designed to suit our manufacturing and production based customers. It features a 900 mm diameter stainless steel collection table strong enough to hold up to 50 kg, and the variable speed controls allow operators to easily adjust the RPM to suit the feeding conveyor. Raised platform sides help prevent goods from falling on the floor and the drain hole (with cover) allows for easy cleaning.

FEATURES

WPROTARY

- high-quality stainless steel frame and collection table
- large rotating collection platform comes with convenient drainage hole (and cover) so that debris can be easily wiped from the table
- 100 mm high sides prevents product from falling on the floor
- engineered to hold up to 50 kg of product at any one time
- variable speed control for adjusting RPM to suit the feeding conveyor
- M16 adjustable swivel feet (x4)
- designed for easy cleaning and ultimate hygiene
- easily integrates with Wedderburn's other packaging machines creating an efficient production line

SPECIFICATIONS

| | |
|---------------------------|-----------------------------|
| Outside table dimensions | 940 mm |
| Internal table dimensions | 900 mm |
| Table depth | 100 mm |
| Overall height | 830 mm (± 30 mm adjustment) |
| Footprint | 620 mm x 620 mm |
| Working area | 950 mm diameter |
| Speed | Adjustable 0 - 50 RPM |
| Working load maximum | 50 kg |
| Net weight | 67 kg |

OPTIONS

- 1200 mm diameter model available on indent (order # WPROTARY1200)



Specifications may change without notice